SFP+
Test Adapter

User Manual

Table of Contents

Introduction 3
Product Inspection 5
The SFP+ Test Adapter Care and Handling Precautions 6
General Test Adapter, Cable, and Connector 8
Handling and Storage 8
Visual Inspection 8
Cleaning 8
Making Connections 8
Electrostatic Discharge Information 9
User Model 10
Mechanical and Environmental Specifications 13
Electrical Specifications 19
Wilder Technologies, LLC – Limited Warranty 27
Wilder Technologies, LLC – Terms & Conditions of Sale 28
Compliance with Environmental Legislation 29
WEEE Compliance Statement 29
Glossary of Terms 30
Index 31

©2011, 2012, 2013 Wilder Technologies, LLC

Introduction

This user's guide documents the SFP+ Plug and Receptacle Test Adapters (SFP+-TPA-HCB-P and SFP+-TPA-MCB-R), and the Low Speed HCB and MCB Switch Module assemblies. The two test adapter types, shown in Figures 1 and 2, test SFP+ interface cables, hosts, and modules to the requirements of the SFF-8431 and SFF-8083 specifications.

The TPA-HCB-P and TPA-MCB-R test adapter assemblies allow easy access, via SMA connections, to measure or inject data signals.

NOTE: To avoid damaging the cables, use the handling techniques described in the Care and Handling section before making any connections or configuring a test setup.

Always use a static-safe workstation when performing tests, as explained in the "Electrostatic Discharge Information" section.


SFP+ Plug Switch Module Assembly
50 Ohm RF Termination (Female, one of four shown. Optional Accessory)
DC Block (One of four shown. Optional Accessory. Note: Actual DC Block may differ than part shown.)
Low-Speed Connector
4 SMAs (male) for High-Speed Testing
SFP+ Plug Connector Assembly

Figure 1. The SFP+ HCB Test Adapter tests to the requirements of the Host Compliance Board (Plug) (Note: Coaxial cables shown are illustrated shorter than those used in the test adapter.)

©2011, 2012, 2013 Wilder Technologies, LLC



Figure 2. The SFP+ MCB Test Adapter tests to the requirements of the Module Compliance Board (Receptacle)

(Note: Coaxial cables shown are illustrated shorter than those used in the test adapter.)

NOTE: The metal shell of both the plug (SFP+-TPA-HCB-P) and receptacle (SFP+-TPA-MCB-R) connectors tie high-speed ground to chassis ground.

The low-speed 12-position receptacle and plug connectors are keyed and latching (Molex part number 43645-1200 for the plug TPA and 43650-1204 for the receptacle TPA). The mating connector housings and contact pins for 26-30awg wire are Molex part number 43640-1201 for the 12-position housing and 43031-0011 for the plug contacts used with the plug TPA, and Molex part number 43645-1200 for the 12-position housing and 43030-011 for the receptacle contacts used with the receptacle TPA. Replacement parts can be purchased through Molex distributors.

NOTE: The receiver SMA connections for SFP+ are normally AC coupled. The SFP+ plug and receptacle TPAs do NOT have internal DC Blocks. This allows for parametric testing through the TPAs. Normal testing may require DC Blocks (May be optionally ordered from Wilder Technologies). Refer to the Electrical Specifications section of this document for DC Block performance parameters.

©2011, 2012, 2013 Wilder Technologies, LLC

Product Inspection

Upon receiving the SFP+ TPA from Wilder Technologies, perform the following product inspection:

- Inspect the outer shipping container, foam-lined instrument case, and product for damage. Retain the outer cardboard shipping container until the contents of the shipment have been inspected for completeness and the product has been checked mechanically and electrically. Use the foam-lined instrument-case for secure storage of the Wilder Technologies SFP+ Test Adapter when not in use.

- Locate the shipping list and verify that all items ordered were received.

- In the unlikely event that the product is defective or incomplete, the “Limited Warranty” section discusses how to contact Wilder Technologies for technical assistance and/or how to package the product for return.

©2011, 2012, 2013 Wilder Technologies, LLC

The SFP+ Test Adapter Care and Handling Precautions

The SFP+ Test Adapter requires careful handling to avoid damage. Improper handling techniques, or using too small a cable bend radius, can damage the coaxial cable connections within the adapter housing or the cables themselves. This can occur at any point along the cable. To achieve optimum performance and to prolong the SFP+ TPA's life, observe the following handling precautions:

- **CAUTION 1: Avoid Torque Forces** (Twisting)
  While individual coaxial cables within the test adapter have some rotational freedom, twisting the SFP+ TPA as a unit, with one end held stationary, may damage or severely degrade performance. Adherence to Caution 5 (below) helps to avoid twisting.

- **CAUTION 2: Avoid Sharp Cable Bends**
  Never bend coaxial cables into a radius of 26 mm (1-inch) or less. Never bend cables greater than 90°. Single or multiple cable bends must be kept within this limit. Bending the SFP+ TPA cables less than a 26mm (1-Inch) radius will permanently damage or severely degrade test adapter performance.

- **CAUTION 3: Avoid Cable Tension** (Pull Forces)
  Never apply tension (pull forces) to an individual coaxial cable that is greater than 2.3 kg (5 lbs.). To avoid applying tension, always place accessories and equipment on a surface that allows adjustment to eliminate tension on the SFP+ TPA and cables. Use adjustable elevation stands or apparatus to accurately place and support the SFP+ TPA.

- **CAUTION 4: Connect the SFP+ TPA First**
  To prevent twisting, bending, or applying tension to the coaxial cables when connecting a SFP+ TPA, always attach the SFP+ TPA to the device under test (DUT) or cable under test before attaching any SMA connectors. Carefully align the SFP+ connectors and then gently push the connectors together until fully seated.

  If the SFP+ TPA must be turned or twisted to make connection to the DUT, avoid using the SFP+ TPA housing alone to make this occur. Try to distribute the torque forces along the length of the test setup and cabling. If this is not possible, it is recommended to first loosen or disconnect the SMA connections at the SFP+ TPA, make the connection to the DUT and then re-tighten or attach the test equipment leads.

  NOTE: Only grip the test adapter housing when inserting or extracting the SFP+ TPA to or from the DUT. Pulling directly on the SFP+ TPA cables or using them to insert the SFP+ TPA may cause damage.

- **CAUTION 5: Carefully Make SMA Connections**
  To connect the SFP+ TPA SMA connectors, follow these steps:

  1. Hold the cable stationary by grasping the cable at the black heat-shrink section near the SMA connector.

  2. Insert the mating SMA barrel and hand-tighten the free-spinning SMA nut onto the connector while avoiding pulling, bending, or twisting the SFP+ TPA coaxial cable.

©2011, 2012, 2013 Wilder Technologies, LLC

3. The SFP+ TPA SMA connectors have flats that accept an open-end 5/16-inch wrench. When attaching instrument cables to the SFP+ TPA, it is recommended that the SFP+ TPA SMA connectors be mechanically held and the test leads be tightened to the equipment manufacturer's torque recommendations, normally 5 in-lbs, using a 5/16-inch open-end wrench.

If the test set-up requires repositioning, first loosen or disconnect the SMA connections to avoid twisting, bending, or tension.

NOTE: A drop in signal amplitude by half or 6db during the testing of a channel may indicate that a cable has been mechanically pulled free of coaxial cable connections internal to the assembly. This could be determined by checking if the cable has any lateral play relative to the TPA. This would only occur when the TPA has exceeded the pull force as specified within the mechanical specification. If the cable cannot be re-seated, the test adapter will need to be sent back to the factory for service.

- **CAUTION 6: Independently Support Instrument Cables or Accessories**
  Excessive weight from instrument cables and/or accessories connected to the SFP+ TPA can cause damage or affect the test adapter performance. Be sure to provide appropriate means to support and stabilize all test set-up components.

- **CAUTION 7: The SFP+-TPA-MCB-R Switch Module is ESD Sensitive**
  The SFP+-TPA-MCB-R Switch Module assembly incorporates electrostatic sensitive components. Additionally, when an active DUT is installed, that device also becomes susceptible to ESD. Observe proper ESD precautions, further discussed later in this document.

©2011, 2012, 2013 Wilder Technologies, LLC

General Test Adapter, Cable, and Connector

Observing simple precautions can ensure accurate and reliable measurements.

Handling and Storage

Before each use of the SFP+ TPA, ensure that all connectors are clean. Handle all cables carefully and store the SFP+ TPA in the foam-lined instrument case when not in use, if possible. Do not set connectors contact end down. Install the SMA protective end caps when the SFP+ TPA is not in use.

Visual Inspection

Be sure to inspect all cables carefully before making a connection. Inspect all cables for metal particles, scratches, deformed threads, dents, or bent, broken, or misaligned center conductors. Do not use damaged cables.

Cleaning

If necessary, clean the connectors using low-pressure (less than 60 PSI) compressed air or nitrogen with an effective oil-vapor filter and condensation trap. Clean the cable threads, if necessary, using a lint-free swab or cleaning cloth moistened with isopropyl alcohol. Always completely dry a connector before use. Do not use abrasives to clean the connectors. Re-inspect connectors, making sure no particles or residue remains.

Making Connections

Before making any connections, review the “Care and Handling Precautions**”** section. Follow these guidelines when making connections:

- Align cables carefully
- Make preliminary connection lightly
- To tighten, turn connector nut only
- Do not apply bending force to cable
- Do not over-tighten preliminary connections
- Do not twist or screw-in cables
- Use a torque wrench, and do not tighten past the “break” point of the torque wrench

©2011, 2012, 2013 Wilder Technologies, LLC

Electrostatic Discharge Information

Protection against electrostatic discharge (ESD) is essential while connecting, inspecting, or cleaning the SFP+ TPA test adapter and connectors attached to a static-sensitive circuit (such as those found in test sets).

Electrostatic discharge can damage or destroy electronic components. Be sure to perform all work on electronic assemblies at a static-safe work station, using two types of ESD protection:

- Conductive table-mat and wrist-strap combination
- Conductive floor-mat and heel-strap combination

When used together, both of these types provide a significant level of ESD protection. Used alone, the table-mat and wrist-strap combination provide adequate ESD protection. To ensure user safety, the static-safe accessories must provide at least 1 MΩ of isolation from ground. Acceptable ESD accessories may be purchased from a local supplier.

WARNING: These techniques for a static-safe work station should not be used when working on circuitry with a voltage potential greater than 500 volts.

©2011, 2012, 2013 Wilder Technologies, LLC

User Model

The SFP+ TPAs are capable of performing to the requirements of SFF-8431 and SFF-8083, limited only by the specifications, environmental, care and handling of this document.

In the case where the laboratory source or load is not used in the test, it must be replaced with RF terminations on each unused signal (RF terminators are optionally offered by Wilder Technologies).

The following examples are suggestions for possible testing setups.

In this first example, a SFP+-TPA-MCB-R and associated Switch Module assembly is used to test a SFP+ Module:



©2011, 2012, 2013 Wilder Technologies, LLC

The second example shows a SFP+-TPA-HCB-P and associated Switch Module assembly is used to test a host:

In the case where the laboratory source or load is not used in the test, it must be replaced with RF terminations on each unused signal (RF terminators are optionally offered by Wilder Technologies).



©2011, 2012, 2013 Wilder Technologies, LLC

The third example shows two SFP+-TPA-MCB TPAs-R's used for testing a SFP+ cable:



©2011, 2012, 2013 Wilder Technologies, LLC

Mechanical and Environmental Specifications

NOTE: All specifications in this manual are subject to change.

Table 1. General Specifications

ITEM	DESCRIPTION
Usage Environment	Controlled indoor environment
Plug Test Adapter Length (w/standard cables)	431.44 mm +/- 2 mm (16.99 inches +/- .08 inches) (Characteristic)
Receptacle Test Adapter Length (w/std. cables)	372.59 mm +/- 2 mm (14.67 inches +/- .08 inches) (Characteristic)
Operating Temperature	0°C to +55°C (32°F to +131°F) (Characteristic)
Storage Temperature	-40°C to +70°C (-40°F to +158°F) (Characteristic)

SFP+-TPA-HCB-P and SFP+-TPA-MCB-R Cable Pinout

The SFP+ TPA cables provide four SMA connectors (one lane of primary differential TX and RX). Labels clearly mark each cable or connector. The following figure refers to the pin-description table for the plug connector.


Low-Speed Connector (See Table 3 & 4)
Pin 1 End (Ref)
4 SMAs for High-Speed Testing
SFP+ Plug Connector (See Table 4)
Color ID for Data Line Polarity (See Table 4)
Color ID for Differential Pair (See Table 2 & 4)

Figure 3. Cable Connectors (SFP+-TPA-HCB-P shown)

©2011, 2012, 2013 Wilder Technologies, LLC

The following figure refers to the SFP+-TPA-HCB-P Switch Module assembly. Refer to SFF-8431 for test details and settings of the Switch Module assembly. (Note: The default settings for switch S1 are Pin-1-Off, Pin-2-Off, Pin-3-Off, Pin-4-NC.)

The mating 3-position receptacle connector housings and contact receptacles for 22-30awg wire are provided with each SFP+-TPA-HCB-P Switch Module assembly, allowing the user to create custom Switch Module cables. (Molex part number 22-01-2035 for the housings and 08-55-0102 for the receptacle contacts). Replacement plug parts can be purchased through Molex distributors.



Figure 4. SFP+-TPA-HCB-P Switch Module



Figure 5. SFP+-TPA-HCB-P Switch Module Schematic

©2011, 2012, 2013 Wilder Technologies, LLC

The following figure refers to the pin-description table for the receptacle connector.



Figure 6. Cable Connectors (SFP+-TPA-MCB-R shown)

©2011, 2012, 2013 Wilder Technologies, LLC

The following figure refers to the SFP+-TPA-MCB-R Switch Module assembly. Refer to SFF-8431 for test details and settings of the Switch Module assembly. (Note: The default settings for switch S1 are Pin-1-On, Pin-2-Off, Pin-3-Off, Pin-4-NC.)

The mating 3-position receptacle connector housings and contact receptacles for 22-30awg wire are provided with each SFP+-TPA-MCB-R Switch Module assembly, allowing the user to create custom Switch Module cables. (Molex part number 22-01-2035 for the housings and 08-55-0102 for the receptacle contacts). Replacement plug parts can be purchased through Molex distributors.



Figure 7. SFP+-TPA-MCB-R Switch Module



Figure 8. SFP+-TPA-MCB-R Switch Module Schematic

©2011, 2012, 2013 Wilder Technologies, LLC

Table 2. SMA Cable Connectors (High-Speed)

LABEL	COLOR ID FOR DIFFERENTIAL PAIR	DESCRIPTION
RD+	Blue	Receive positive for Host, Transmit positive for Module
RD-	Blue	Receive negative for Host, Transmit negative for Module
TD+	Yellow	Transmit positive for Host, Receive positive for Module
TD-	Yellow	Transmit negative for Host, Receive negative for the Module

Table 3. SFP+-TPA 12-Position Cable Connector (Low-Speed)

LABEL	PIN NO.	COLOR ID FOR HCB/MCB	DESCRIPTION
GND	Pin 1	Black/NA	VeeR and VeeT, RF Ground
TXF	Pin 2	Black/NA	Tx_Fault, Transmit fault
TXD	Pin 3	Black/NA	Tx_Disable, Transmit disable
SDA	Pin 4	Black/NA	SDA, I^2C Data for DDC
SCL	Pin 5	Black/NA	SCL, I^2C Clock for DDC
ABS	Pin 6	Black/NA	MOD_ABS, Module absent
RS0	Pin 7	Black/NA	RS0, Rate select 0
LOS	Pin 8	Black/NA	Rx_LOS, Loss of Receive Signal
RS1	Pin 9	Black/NA	RS1, Rate select 1
VCR	Pin 10	Black/NA	VccR, module receiver power supply
VCT	Pin 11	Black/NA	Vcct, module transmitter power supply
GND	Pin 12	Black/NA	VeeR and VeeT, RF Ground

©2011, 2012, 2013 Wilder Technologies, LLC

Table 4. SFP+ Plug and Receptacle Pin Assignments

Pin Description	Connector Pin Number	Destination Number (HCB/MCB)	Color ID for Data Line Polarity	Color Identification (HCB/MCB)
RF Ground	1	P2/J2 Pin 1, Pin 12	N/A	Black Insulation/NA
Tx Fault	2	P2/J2 Pin 2	N/A	Black Insulation/NA
Tx Disable	3	P2/J2 Pin 3	N/A	Black Insulation/NA
SDA	4	P2/J2 Pin 4	N/A	Black Insulation/NA
SCL	5	P2/J2 Pin 5	N/A	Black Insulation/NA
Mod_ABS	6	P2/J2 Pin 6	N/A	Black Insulation/NA
RS0	7	P2/J2 Pin 7	N/A	Black Insulation/NA
Rx_LOS	8	P2/J2 Pin 8	N/A	Black Insulation/NA
RS1	9	P2/J2 Pin 9	N/A	Black Insulation/NA
RF Ground	10	P2/J2 Pin 1, Pin 12	N/A	Black Insulation/NA
RF Ground	11	P2/J2 Pin 1, Pin 12	N/A	Black Insulation/NA
RD-	12	RD-	Black	Blue Label
RD+	13	RD+	Red	Blue Label
RF Ground	14	P2/J2 Pin 1, Pin 12	N/A	Black Insulation/NA
VccR	15	P2/J2 Pin 10	N/A	Black Insulation/NA
VccT	16	P2/J2 Pin 11	N/A	Black Insulation/NA
RF Ground	17	P2/J2 Pin 1, Pin 12	N/A	Black Insulation/NA
TD+	18	TD+	Red	Yellow Label
TD-	19	TD-	Black	Yellow Label
RF Ground	20	P2/J2 Pin 1, Pin 12	N/A	Black Insulation/NA



©2011, 2012, 2013 Wilder Technologies, LLC

Electrical Specifications

NOTE: All specifications in this manual are subject to change.

Table 5. Electrical Specifications (TPA)

SPECIFICATION	MIN	TYP	MAX	NOTES
Insertion Loss (db), at 5 GHz	-1.18	-0.97	-0.87	HCB TPA without Connector and Pad.
Insertion Loss (db), at 5 GHz	-0.56		-0.36	MCB TPA without Connector and Pad.
Insertion Loss (db), at 5 GHz	-2.2	-1.83	-1.64	Mated HCB and MCB TPAs with Connectors and Pads.
Return Loss (GHz), at -20 db		3.3		Mated HCB and MCB TPAs with Connectors and Pads.
Differential Impedance (ohms), 34 ps Rise Time, 20 – 80%	90		110	All Differential Pairs, Receptacle and Plug, excluding SFP+ connector
Differential Impedance (ohms), 34 ps Rise Time, 20 – 80%	80		120	All Differential Pairs, Receptacle and Plug, including SFP+ connector.
Impedance (ohms), 34 ps Rise Time, 20 – 80%	45		55	Single-ended signals within differential pairs, Receptacle and Plug, excluding SFP+ connector
Intra-pair Skew (ps)	-6		6	All Differential Pairs, Receptacle and Plug
Inter-pair Skew (ps)	-6		6	All Differential Pairs, Receptacle and Plug
NEXT (db), at 5 GHz	-45			Single aggressor, with SFP+ connector, mated HCB to MCB, with standard coaxial cables and terminations

©2011, 2012, 2013 Wilder Technologies, LLC

Table 6. Electrical Specifications (Optional External DC Block) as Supplied by Wilder Technologies

SPECIFICATION	MIN	TYP	MAX	NOTES
Insertion Loss (db), at 100 kHz - 12.4 GHz at 12.4 - 26.5 GHz		 0.50 0.75		
VSWR, 7kHz TO 26.5 GHz			1.35	
Upper -3db Bandwidth (GHz)	26.5			
Lower -3db Bandwidth (kHz)			7	
Voltage		100 Volts Max.		
In-Line Capacitance (µF)		0.474		
Impedance (Ohms)		50		

Table 7. Electrical Specifications (Optional RF Termination) as Supplied by Wilder Technologies

SPECIFICATION	MIN	TYP	MAX	NOTES
VSWR, DC to 4 GHz 4 to 12.4 GHz 12.4 to 18 GHz			 1.05 1.15 1.20	
Frequency Range (GHz)	DC		18	
Power Dissipation (Watts)			2	Power derates linearly from 100% ≤ 25°C to 10% @ 125°C
Impedance (Ohms)		50		

©2011, 2012, 2013 Wilder Technologies, LLC



Figure 9. Typical mated pair 10 Gb/s eye diagram.



Figure 10. Typical mated pair 10 Gb/s eye data.

©2011, 2012, 2013 Wilder Technologies, LLC



Figure 11. Typical mated pair balanced insertion loss.



Figure 12. Available S4Ps showing balanced insertion loss of HCB without connector, MCB without connector, and HCB Through MCB without connectors.

©2011, 2012, 2013 Wilder Technologies, LLC



Figure 13. Typical mated pair balanced return loss.



Figure 14. Available S4Ps showing balanced return loss of HCB without connector, MCB without connector, and HCB through MCB without connectors.

©2011, 2012, 2013 Wilder Technologies, LLC



Figure 15. Typical differential TDR of SFP+-TPA-HCB-P connected to SFP+-TPA-MCB-R at 34ps Rise Time (20-80%) (Measured at 50 ps 10-90%).

©2011, 2012, 2013 Wilder Technologies, LLC



Figure 16. Typical mated pair common mode return loss.



Figure 17. Typical mated pair differential to common mode conversion.

©2011, 2012, 2013 Wilder Technologies, LLC



Figure 18. Typical Differential NEXT, with mated connectors, adjacent differential pairs, both transmit and receive terminated at both ends.

Figure 19. Typical Differential FEXT, with mated connectors, adjacent differential pairs, both transmit and receive terminated at both ends.

©2011, 2012, 2013 Wilder Technologies, LLC

Wilder Technologies, LLC – Limited Warranty

Wilder Technologies, LLC warrants that each Test Adapter, 1) is free from defects in materials and workmanship and, 2) conforms to Wilder Technologies specifications for a period of 12 months. **See Consumable and Fragile Material Warranty for exceptions to the 12 month warranty**

The warranty period for a Test Adapter is a specified, fixed period commencing on the date of ship from Wilder Technologies, LLC. If you did not purchase your Test Adapter directly from Wilder Technologies, LLC, the serial number and a valid proof of purchase will be required to establish your purchase date. If you do not have a valid proof of purchase, the warranty period will be measured from the date of ship from Wilder Technologies, LLC.

If, during the warranty period, the Test Adapter is not in good working order, Wilder Technologies, LLC will, at its option, repair or replace it at no additional charge, except as is set forth below. In some cases, the replacement Test Adapter may not be new and may have been previously installed. Regardless of the Test Adapter's production status, Wilder Technologies, LLC appropriate warranty terms apply.

Consumable and Fragile Material Warranty
Wilder Technologies, LLC warrants that consumable materials and all fragile materials supplied by Wilder Technologies, LLC either as part of an instrument or system, or supplied separately, will be free from defects in material and workmanship at the time of shipment.

Extent of Warranty
The warranty does not cover the repair or exchange of a Test Adapter resulting from misuse, accident, modification, unsuitable physical or operating environment, improper maintenance by you, or failure caused by a product for which Wilder Technologies, LLC is not responsible. The warranty is voided by removal or alteration of Test Adapter or parts identification labels. The initial three months are unconditional; the remaining months excludes plugs, receptacles and SMA connectors. Connectors are wear items and excluded from the warranty after the initial three months.

These warranties are your exclusive warranties and replace all other warranties or conditions, express or implied, including but not limited to, the implied warranties or conditions or merchantability and fitness for a particular purpose. These warranties give you specific legal rights and you may also have other rights which vary from jurisdiction to jurisdiction. Some jurisdictions do not allow the exclusion or limitation of express or implied warranties, so the above exclusion or limitation may not apply to you. In that event, such warranties are limited in duration to the warranty period. No warranties apply after that period.

Items Not Covered by Warranty
Wilder Technologies, LLC does not warrant uninterrupted or error–free operation of a Test Adapter.

Any technical or other support provided for a Test Adapter under warranty, such as assistance via telephone with "how–to" questions and those regarding Test Adapter set-up and installation, will be provided **WITHOUT WARRANTIES OF ANY KIND**.

Warranty Service
Warranty service may be obtained from Wilder Technologies, LLC by returning a Wilder Technologies, LLC Returns Material Authorization and the Test Adapter to Wilder Technologies, LLC during the warranty period. To obtain RMA number, contact support@wilder-tech.com.

You may be required to present proof of purchase or other similar proof of warranty entitlement. You are responsible for any associated transportation charges, duties and insurance between you and Wilder Technologies, LLC. In all instances, you must ship Test Adapters in Wilder Technologies, LLC approved packaging. Information on packaging guidelines can be found at: www.wilder-tech.com. Wilder Technologies, LLC will ship repaired or replacement Test Adapter Delivery Duty Prepaid (DDP) and will pay for return shipment. You will receive title to the repaired or replacement Test Adapter and you will be the importer of record.

©2011, 2012, 2013 Wilder Technologies, LLC

Wilder Technologies, LLC – Terms & Conditions of Sale

1. **Other Documents:** This Agreement may NOT be altered, supplemented, or amended by the use of any other document(s) unless otherwise agreed to in a written agreement signed by both you and Wilder Technologies, LLC. If you do not receive an invoice or acknowledgement in the mail, via e-mail, or with your Product, information about your purchase may be obtained at support@wilder-tech.com or by contacting your sales representative.

2. **Payment Terms, Orders, Quotes, Interest:** Terms of payment are within Wilder Technologies, LLC's sole discretion, and unless otherwise agreed to by Wilder Technologies, LLC, payment must be received by Wilder Technologies, LLC prior to Wilder Technologies, LLC's acceptance of an order. Payment for the products will be made by credit card, wire transfer, or some other prearranged payment method unless credit terms have been agreed to by Wilder Technologies, LLC. Invoices are due and payable within the time period noted on your invoice, measured from the date of the invoice. Wilder Technologies, LLC may invoice parts of an order separately. Your order is subject to cancellation by Wilder Technologies, LLC, in Wilder Technologies, LLC's sole discretion. Unless you and Wilder Technologies, LLC have agreed to a different discount, Wilder Technologies, LLC's standard pricing policy for Wilder Technologies, LLC-branded systems, which includes hardware, software and services in one discounted price, allocates the discount off list price applicable to the service portion of the system to be equal to the overall calculated percentage discount off list price on the entire system. Wilder Technologies, LLC is not responsible for pricing, typographical, or other errors in any offer by Wilder Technologies, LLC and reserves the right to cancel any orders resulting from such errors.

3. **Shipping Charges; Taxes; Title; Risk of Loss:** Shipping, handling, duties and tariffs are additional unless otherwise expressly indicated at the time of sale. Title to products passes from Wilder Technologies, LLC to Customer on shipment from Wilder Technologies, LLC's facility. Loss or damage that occurs during shipping by a carrier selected by Wilder Technologies, LLC is Wilder Technologies, LLC's responsibility. Loss or damage that occurs during shipping by a carrier selected by you is your responsibility. You must notify Wilder Technologies, LLC within 7 days of the date of your invoice or acknowledgement if you believe any part of your purchase is missing, wrong or damaged. Unless you provide Wilder Technologies, LLC with a valid and correct tax exemption certificate applicable to your purchase of Product and the Product ship-to location, you are responsible for sales and other taxes associated with the order. **Shipping dates are estimates only**.

4. **WARRANTY:** WILDER TECHNOLOGIES, LLC, warrants that the item(s) manufactured under the Buyer's contract shall be free from defects in materials and workmanship furnished by WILDER TECHNOLOGIES, LLC, and shall conform to the applicable drawings and specifications. WILDER TECHNOLOGIES, LLC'S liability herein, for breach of warranty, contract or negligence in manufacturing, shall be limited to repair or replacement. Repair or replacement of defective items will be applicable only if the Buyer notifies WILDER TECHNOLOGIES, LLC, by written notice within 30-days of delivery. All claims shall be addressed to: support@wilder-tech.com or WILDER TECHNOLOGIES, LLC, 6101A East 18th Street, Vancouver, Washington 98661 U.S.A.; ATTENTION: Customer Service Manager. WILDER TECHNOLOGIES, LLC, reserves the right to inspect at the Buyer's plant all items claimed to be defective or nonconforming prior to authorizing their return. WILDER TECHNOLOGIES, LLC, assumes no liability for the results of the use of its components in conjunction with other electric, electronic or mechanical components, circuits and/or systems. The foregoing constitutes the sole and exclusive remedy of the Buyer and the exclusive liability of WILDER TECHNOLOGIES, LLC, and is IN LIEU OF ANY AND ALL OTHER WARRANTIES, STATUTORY, IMPLIED OR EXPRESSED AS TO MERCHANTABILITY, FITNESS FOR THE PURPOSE SOLD, DESCRIPTION, QUALITY, and PRODUCTIVENESS OR ANY OTHER MATTER. Without limiting the foregoing, in no event shall WILDER TECHNOLOGIES, LLC, be liable for loss of use, profit or other collateral, or for special and/or consequential damages.

5. **RETURNED GOODS:** WILDER TECHNOLOGIES, LLC, will accept only those goods for return that have been authorized for return. All goods authorized for return shall be assigned a Returned Material Authorization (RMA) Number. The RMA Number shall be clearly marked on the shipping container(s) and all documentation accompanying the goods authorized for return. The RMA Number shall be assigned by WILDER TECHNOLOGIES, LLC pursuant to the conditions set forth in Paragraph 4, WARRANTY.

6. **UNITED STATES GOVERNMENT CONTRACTS:** In the event this offer is accepted under Government contract, WILDER TECHNOLOGIES, LLC, agrees to accept clauses required by Government regulations and to waive WILDER TECHNOLOGIES, LLC conditions inconsistent therewith. WILDER TECHNOLOGIES, LLC, certifies that it is a regular manufacturer or dealer of the goods and/or services offered herein and that the prices offered do not exceed those charged to any customer for like quantities, services or materials under the same conditions.

©2011, 2012, 2013 Wilder Technologies, LLC

Compliance with Environmental Legislation

Wilder Technologies, LLC, is dedicated to complying with the requirements of all applicable environmental legislation and regulations, including appropriate recycling and/or disposal of our products.

WEEE Compliance Statement

The European Union adopted Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE), with requirements that went into effect August 13, 2005. WEEE is intended to reduce the disposal of waste from electrical and electronic equipment by establishing guidelines for prevention, reuse, recycling and recovery.

Wilder Technologies has practices and processes in place to conform to the requirements in this important Directive.

In support of our environmental goals, effective January 1st, 2009 Wilder Technologies, LLC has partnered with E-Tech Recycling of Beaverton, Oregon, www.etechrecycling.com, to recycle our obsolete and electronic waste in accordance with the European Union Directive 2002/96/EC on waste electrical and electronic equipment ("WEEE Directive").

As a service to our customers, Wilder Technologies is also available for managing the proper recycling and/or disposal of all Wilder Technologies products that have reached the end of their useful life. For further information and return instructions, contact support@wilder-tech.com.

©2011, 2012, 2013 Wilder Technologies, LLC

Glossary of Terms

TERMINOLOGY	DEFINITION
Aggressor	A signal imposed on a system (i.e., cable assembly) to measure response on other signal carriers.
Decibel (dB)	Ten times the common logarithm (i.e. log10) of the ratio of relative powers.
Far-end crosstalk or FEXT	Crosstalk that is propagated in a disturbed channel in the same direction as the propagation of a signal in the aggressor channel. The terminals of the aggressor channel and the victim channel are usually close to each other.
Informative	The designation of a test that is not required for compliance.
Insertion loss	The ratio, expressed in dB, of incident power to delivered power.
Near-end crosstalk or NEXT	Crosstalk that is propagated in a disturbed channel in the opposite direction as the propagation of a signal in the aggressor channel. The terminals of the aggressor channel and the victim channel are usually close to each other.
Normative	The designation of a test that is required for compliance.
Return Loss	The ratio, expressed in dB, of incident power to reflected power.
SFP+	Enhanced Small Form Factor Pluggable connection
SFP+ Host	The SFP+ Host is the fixed end of the connection supporting IEEE 802.3 (clauses 38, 49, 52, 59, or 68), 8 GFC, 10 GFC, and 10GSFP+Cu serial protocols.
SFP+ Module	The SFP+ Module is the moveable end of the connection supporting IEEE 802.3 (clauses 38, 49, 52, 59, or 68), 8 GFC, 10 GFC, and 10GSFP+Cu serial protocols.
SFP+ TPA	SFP+ Test Point Access. A specialized assembly that interfaces to a SFP+ host or module and enables access of signals for measurement or stimulation.
Victim	A signal carrier on a system that has a response imposed on it by other signals in the system.

©2011, 2012, 2013 Wilder Technologies, LLC

Index

AC coupled, 4
Cable Bend Limits, 6
Cable Tension (Pull Forces), 6
Cable Twisting (Torque), 6
Care and Handling, 6
Cleaning, 8
Compliance
  WEEE, 29
Connections
  SFP+-TPA to DUT, 6
  SMA, 6, 7
DC Blocks, 4, 10, 11
Electrical Specifications, 19
Electrostatic Discharge Information (ESD), 9
ESD protection, 9
ESD Sensitivity, 7
Figures
  Cable Connectors, 13, 15
  SFP+-TPA-HCB-P Switch Module, 14
  SFP+-TPA-HCB-P Switch Module Schematic, 14
  SFP+-TPA-MCB-R Switch Module, 16
  SFP+-TPA-MCB-R Switch Module Schematic, 16
  The SFP+ HCB Test Adapter (Plug), 3
  The SFP+ MCB Test Adapter (Receptacle), 4
Glossary, 30
Handling and Storage, 8
Low-Speed Connector, 4
Low-Speed Connector Part Numbers, 4
Making Connections, 8
Mechanical and Environmental Specifications, 13
Molex part numbers, 4
Product Inspection, 5
Product Return, 5
Pull Force, 6, 7
RF Terminations, 3, 4, 10, 11
Secure Storage, 5
SFF Specification, 3, 14, 16
SFP+-TPA-HCB-P Cable Pinout, 13
SFP+-TPA-HCB-P Plug TPA Testing a Host, 11
SFP+-TPA-MCB -R Testing a SFP+ Module, 10
SFP+-TPA-MCB-R Cable Pinout, 13
SFP+-TPA-MCB-R's Testing a SFP+ Cable, 12
SMA cables, 13
Support, 28
Supporting Instrument Cables or Accessories, 7
Tables
  Electrical Specifications (External DC Block), 20
  Electrical Specifications (RF Termination), 20
  Electrical Specifications (TPA), 19
  General Specifications, 13
  SFP+ Plug & Recept. Pin Assignments, 18
  SFP+-TPA 12-Position Cable Connector, 17
  SMA Cable Connectors (High-Speed), 17
Terms and Conditions of Sale, 28
User Model Examples, 10, 11, 12
Visual Inspection, 8
Warranty, 27
Web Sites
  support@wilder-tech.com, 27, 28
  www.etechrecycling.com, 29
  www.wilder-tech.com, 27
WEEE, 29

©2011, 2012, 2013 Wilder Technologies, LLC

Visit our website at www.wilder-tech.com

Wilder Technologies, LLC
6101A East 18th Street
Vancouver, WA 98661
Phone: 360-859-3041
Fax: 360-859-3105
www.wilder-tech.com

©2011, 2012, 2013 Wilder Technologies, LLC
Document No. 910-0019-000 Rev. D
Created: 10/24/2011 Updated: 2/6/2013